






Video Camera Features



1	Power Button	Press to turn on/off.
2	Wrist Strap Hook	Attach wrist strap (included in package).
3	HDMI Mini Port	Connect HDMI cable accessory to your HDTV.
4	Tripod Mount	Attach a tripod or a Flip Video accessory.
5	Recording Light	Red light turns on during recording or charging. Built-in stereo microphone is also located here.
6	USB Arm	Connect to a PC or Mac USB port.
7	USB Latch	Slide down to release USB arm.
8	Screen	Recording viewfinder/playback screen.
9	Recording Controls	Touch buttons to record and preview videos.
	Record Button	 Touch to start/stop recording. <i>During Power On:</i> Hold to return to video camera setup.
	Play Button	 Touch to play/pause playback. Touch and hold to play all videos.
	Delete Button	 Touch to delete. Touch and hold to lock/unlock the delete button.
	Up/Down Buttons	 <i>While recording:</i> touch and hold to zoom in/out. <i>During playback:</i> touch and hold to increase/decrease volume.
	Left/Right Buttons	 <i>While paused:</i> touch to skip to previous/next video. <i>During playback:</i> touch and hold to rewind/fast-forward.